

**DNP3 Device Profile**  
**Based on DNP XML Schema version 2.10.00**

**Document Name: TMW SDNP Library Device Profile**

**Revision History**

Date	Time	Version	Reason for change	Edited by
2021-10-28	11:30:00	1.00	Version 3.20.000 SDNP SCL	ITB

**REFERENCE DEVICE:**

**1 Device Properties**

This document is intended to be used for several purposes, including:

-Identifying the capabilities of a DNP3 device (Master Station ou Outstation)

- Recording the settings of a specific instance of a device (paramter settings for a specific instance of the device in the user’s manual total DNP3 estate)

-Matching user requirements to product capabilities when procuring a DNP3 device

The document is therefore structured to show, for each technical feature, the capabilities of the device (or capabilities required by the device when procuring).

It is also structured to show the current value (or setting) of eachof the parameters that describe a specific instance of the device. This “current value” may also show a functional limitation of the device. For example when implementing secure authentication it is not required that all DNP3 devices accept aggressive mode request during critical exchanges (see Device Profile 1.12.4), in which case a vendor would mark this current value as “No-does not accept aggressive mode requests”.

Additionally, the current value may sometimes be used to show a value that a device can achieve because of hardware or software dependencies. Na example of this is in section 1.6.8 of the Device Profile (Maximum error in the time that the Master issues freeze request) where the value may well depend upon tolerances of hardware components and interactions between software tasks. When the Device Profile current value is used in this way the corresponding entry in the capabilities column is grayed-out. Users should note that if na entry in the capabilities column of the Device Profile is grayed-out then there mau be information in the current value column that us pertinente to the device’s capabilities.

Unless otherwisw noted, multiple boxes in the second column below are selected for each parameter to indicate all capabilities supported or required. Parameters without checkboxes in the second column do not have capabilities and are included so that the current value may be shown in the third column.

The items listed in the capabilities column below may be configurable to any of the options selected, or set to a fixed value when the device was designed.

Item 1.1.10 contains a list of abbreviations for possible qays in hich the configurable parameters may be set. Since some parameters may not be Accessible by each of these methods supported, na abrbreviation for the configuration method supported by each parameter is shown in the fourth column of the tables below.

If this document is used to show the current values, the third column should be filled in even if a fixed parameter is selected in the capabilities section (“NA” May be entered for parameters that are Not Applicable).

Ih the document is used to show the current values of parameters, the column 3 applies to a single connection between a máster and na outstation.

1.1 DEVICE IDENTIFICATION	Capabilities	Current Value	if configurable list methods
1.1.1 Device Function:  <i>Masters send DnP requests while Outstation send DNP responses. If a single physical device can perform both functions, a separate Device Profile Document must be provided for each function.</i>	<input type="radio"/> Master <input checked="" type="radio"/> Outstation	<input type="radio"/> Master <input checked="" type="radio"/> Outstation	
1.1.2 Vendor Name:  <i>The name of the organization producing the device.</i>		ITB – Equipamentos Elétricos Ltda	
1.1.3 Device Name:  <i>The model and name of device, suficiente to distinguish it from any other device from the same organization.</i>		CTR-3X	
1.1.4 Device manufacturer’s hadware version String:		1.00	
1.1.5 Device manufacturer’s software version string:		1.00	

<p>1.1.6 Device Profile Document Version Number:</p> <p><i>Version of the Device Profile Document is indicated by a whole number incremented with each new release. This should match the latest version shown in the revision History at the beginning of this document.</i></p>		1																													
<p>1.1.7 DNP Levels Supported for:</p> <p><i>Indicate each DNP3 Level to which the device conforms fully, For Masters, requests and responses can be indicated independently</i></p>	<p>Outstations Only Requests and Responses</p> <ul style="list-style-type: none"> <li><input checked="" type="checkbox"/> None</li> <li><input checked="" type="checkbox"/> Level 1</li> <li><input checked="" type="checkbox"/> Level 2</li> <li><input type="checkbox"/> Level 3</li> <li><input type="checkbox"/> Level 4</li> </ul>	Level 2																													
<p>1.1.8 Supported Function Blocks</p>	<ul style="list-style-type: none"> <li><input checked="" type="checkbox"/> Self Address Support</li> <li><input type="checkbox"/> Data Sets</li> <li><input type="checkbox"/> File Transfer</li> <li><input type="checkbox"/> Virtual Terminal</li> <li><input type="checkbox"/> Mapping to IEC 61850 Object Models defined in a DNP3 XML file</li> <li><input type="checkbox"/> Function code 31, activate configuration</li> <li><input type="checkbox"/> Secure Authentication (if checked then see 1.12)</li> </ul>	Self Address																													
<p>1.1.9 Notable Additions:</p> <p><i>A brief description intended to quickly identify (for the reader) the most obvious features the device supports in addition to the Highest DNP Level Supported. The complete list of features is described in the Implementation Table.</i></p>																															
<p>1.1.10 Methods to set Configurable Parameters</p>	<ul style="list-style-type: none"> <li><input type="checkbox"/> XML – Loaded via DNP3 File Transfer</li> <li><input type="checkbox"/> XML – Loaded via other transport mechanism</li> <li><input type="checkbox"/> Terminal – ASCII Terminal Command Line</li> <li><input checked="" type="checkbox"/> Software – Vendor software named CTR3Comm1.01</li> <li><input type="checkbox"/> Proprietary file loaded via DNP3 File Transfer</li> <li><input type="checkbox"/> Proprietary file loaded via other transport mechanism</li> <li><input checked="" type="checkbox"/> Direct – Keypad on device front panel</li> <li><input type="checkbox"/> Factory – Specified when device is ordered</li> <li><input checked="" type="checkbox"/> Protocol – Set via DNP3 (e.g. assign class)</li> <li><input type="checkbox"/> Other – explain:</li> </ul>	Software Vendor software named <b>CTR-3XComm</b> Version <b>1.1</b> Direct Protocol	Software <b>CTR-3XComm</b> Vers <b>1.1</b> -----																												
<p>1.1.11 DNP3 XML files available On-line:</p> <p><i>XML configuration file names that can be read or written through DNP3 File Transfer to a device.</i></p> <p><i>A device's currently running configuration is returned by DNP3 on-line XML file read from the device.</i></p> <p><i>DNP3 on-line XML file write to a device will update the device's configuration when the Activate Configuration (function code 31) is received</i></p>	<table border="0"> <thead> <tr> <th><u>Rd</u></th> <th><u>Wr</u></th> <th><u>Filename</u></th> <th><u>Description of Contents</u></th> </tr> </thead> <tbody> <tr> <td><input type="checkbox"/></td> <td></td> <td>dnpDP.xml</td> <td>Complete Device Profile</td> </tr> <tr> <td><input type="checkbox"/></td> <td></td> <td>dnpDPCAP.xml</td> <td>Device Profile Capabilities</td> </tr> <tr> <td><input type="checkbox"/></td> <td></td> <td>dnpDPCfg.xml</td> <td>Device Profile config values</td> </tr> </tbody> </table>	<u>Rd</u>	<u>Wr</u>	<u>Filename</u>	<u>Description of Contents</u>	<input type="checkbox"/>		dnpDP.xml	Complete Device Profile	<input type="checkbox"/>		dnpDPCAP.xml	Device Profile Capabilities	<input type="checkbox"/>		dnpDPCfg.xml	Device Profile config values	<table border="0"> <thead> <tr> <th><u>Rd</u></th> <th><u>Wr</u></th> <th><u>Filename</u></th> </tr> </thead> <tbody> <tr> <td><input type="checkbox"/></td> <td></td> <td>dnpDP.xml</td> </tr> <tr> <td><input type="checkbox"/></td> <td></td> <td>dnpDPCap.xml</td> </tr> <tr> <td><input type="checkbox"/></td> <td></td> <td>dnpDPCfg.xml</td> </tr> </tbody> </table>	<u>Rd</u>	<u>Wr</u>	<u>Filename</u>	<input type="checkbox"/>		dnpDP.xml	<input type="checkbox"/>		dnpDPCap.xml	<input type="checkbox"/>		dnpDPCfg.xml	
<u>Rd</u>	<u>Wr</u>	<u>Filename</u>	<u>Description of Contents</u>																												
<input type="checkbox"/>		dnpDP.xml	Complete Device Profile																												
<input type="checkbox"/>		dnpDPCAP.xml	Device Profile Capabilities																												
<input type="checkbox"/>		dnpDPCfg.xml	Device Profile config values																												
<u>Rd</u>	<u>Wr</u>	<u>Filename</u>																													
<input type="checkbox"/>		dnpDP.xml																													
<input type="checkbox"/>		dnpDPCap.xml																													
<input type="checkbox"/>		dnpDPCfg.xml																													
<p>1.1.12 External DNP3 XML files available Off-line:</p> <p><i>XML configuration file names that can be read or written from an external system, typically from a system that maintains the outstation configuration.</i></p> <p><i>External off-line XML file read permits an XML definition of new configuration to be supplied from off-line configuration tools.</i></p>	<table border="0"> <thead> <tr> <th><u>Rd</u></th> <th><u>Wr</u></th> <th><u>Filename</u></th> <th><u>Description of Contents</u></th> </tr> </thead> <tbody> <tr> <td><input type="checkbox"/></td> <td></td> <td>dnpDP.xml</td> <td>Complete Device Profile</td> </tr> <tr> <td><input type="checkbox"/></td> <td></td> <td>dnpDPCAP.xml</td> <td>Device Profile Capabilities</td> </tr> <tr> <td><input type="checkbox"/></td> <td></td> <td>dnpDPCfg.xml</td> <td>Device Profile config values</td> </tr> </tbody> </table>	<u>Rd</u>	<u>Wr</u>	<u>Filename</u>	<u>Description of Contents</u>	<input type="checkbox"/>		dnpDP.xml	Complete Device Profile	<input type="checkbox"/>		dnpDPCAP.xml	Device Profile Capabilities	<input type="checkbox"/>		dnpDPCfg.xml	Device Profile config values	<table border="0"> <thead> <tr> <th><u>Rd</u></th> <th><u>Wr</u></th> <th><u>Filename</u></th> </tr> </thead> <tbody> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDP.xml</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCap.xml</td> </tr> <tr> <td><input type="checkbox"/></td> <td><input type="checkbox"/></td> <td>dnpDPCfg.xml</td> </tr> </tbody> </table>	<u>Rd</u>	<u>Wr</u>	<u>Filename</u>	<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml	<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml	
<u>Rd</u>	<u>Wr</u>	<u>Filename</u>	<u>Description of Contents</u>																												
<input type="checkbox"/>		dnpDP.xml	Complete Device Profile																												
<input type="checkbox"/>		dnpDPCAP.xml	Device Profile Capabilities																												
<input type="checkbox"/>		dnpDPCfg.xml	Device Profile config values																												
<u>Rd</u>	<u>Wr</u>	<u>Filename</u>																													
<input type="checkbox"/>	<input type="checkbox"/>	dnpDP.xml																													
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCap.xml																													
<input type="checkbox"/>	<input type="checkbox"/>	dnpDPCfg.xml																													

<p><i>External off-line XML file write permits no XML definition of a new configuration to be supplied to off-line configuration tools.</i></p>			
<p>1.1.13 Connections Supported:</p>	<p><input checked="" type="checkbox"/> Serial (complete section 1.2)  <input type="checkbox"/> IP Networking (complete section 1.3)  <input type="checkbox"/> Other, explain</p>	<p>Serial</p>	<p>Protocol  -----  --</p>
<p>1.1.14 Conformance Testing:</p> <p><i>Where conformance testing has been completed for the outstation or master station, specify the version of the published DNP3 test procedures that was successfully passed. If independently tested, identify the organization that performed the test.</i></p>	<p><input type="checkbox"/> Self-tested, version   <input type="checkbox"/> Independently tested, version</p>		

1.2 SERIAL CONNECTIONS	Capabilities	Current Value	If configurable list methods
<p>1.2.1 Port Name:</p> <p><i>Name used to reference the communications port defined in this section.</i></p>		<p>232-COM1</p>	
<p>1.2.2 Serial Connection Parameters:</p>	<p><input checked="" type="checkbox"/> Asynchronous – 8 Data Bits, 1 Start Bit, 1 Stop bit, No Parity  <input type="checkbox"/> Other, explain</p> <p>Note: Implemented in Target Layer</p>	<p>Asynchronous</p>	

<p>1.2.3 Baud Rate:</p>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input checked="" type="checkbox"/> Configurable, selectable from <b>2400, 4800, 9600, 14400, 19200, 38400, 56000, 115200</b> <input type="checkbox"/> Configurable, other, describe  <div style="background-color: #90EE90; padding: 2px;">Note: Implemented in Target Layer</div>	9600	
<p>1.2.4 Hardware Flow Control (Handshaking):</p> <p><i>Describe hardware signaling requirements of the interface.</i></p> <p><i>Where a transmitter or receiver is inhibited until a given control signal is asserted, it is considered to require that signal prior to sending or receiving characters.</i></p> <p><i>Where a signal is asserted prior to transmitting, that signal will be maintained active until after the end of transmission.</i></p> <p><i>Where a signal is asserted to enable reception, any data sent to the device when the signal is not active could be discarded.</i></p>	<input checked="" type="checkbox"/> None <b>RS-232 / V.24 / V.28 Options:</b> <u>Asserts:</u> <input type="checkbox"/> RTS Before Tx <input type="checkbox"/> DTR Before Tx <input type="checkbox"/> RTS Before Rx <input type="checkbox"/> DTR Before Rx <input type="checkbox"/> Always RTS <input type="checkbox"/> Always DTR <u>Requires Before Tx:</u> CTS <input type="checkbox"/> Asserted <input type="checkbox"/> Deasserted DCD <input type="checkbox"/> Asserted <input type="checkbox"/> Deasserted DSR <input type="checkbox"/> Asserted <input type="checkbox"/> Deasserted RI <input type="checkbox"/> Asserted <input type="checkbox"/> Deasserted <input type="checkbox"/> Requires Rx Inactive before Tx <u>Requires Before Rx:</u> CTS <input type="checkbox"/> Asserted <input type="checkbox"/> Deasserted DCD <input type="checkbox"/> Asserted <input type="checkbox"/> Deasserted DSR <input type="checkbox"/> Asserted <input type="checkbox"/> Deasserted RI <input type="checkbox"/> Asserted <input type="checkbox"/> Deasserted <u>Always Ignores:</u> <input type="checkbox"/> CTS <input type="checkbox"/> DCD <input type="checkbox"/> DSR <input type="checkbox"/> RI <input type="checkbox"/> Other, explain  <b>RS-422 / V.11 Options:</b> <input type="checkbox"/> Requires Indication before Rx <input type="checkbox"/> Asserts Control before Tx <input type="checkbox"/> Other, explain  <b>RS-485 Options:</b> <input type="checkbox"/> Requires Rx inactive before Tx <input type="checkbox"/> Other, explain  <input checked="" type="checkbox"/> Other, explain <b>Software</b>	None <b>RS-232 / V.24 / V.28 Options:</b>  <b>RS-422 / V.11 Options:</b>  <b>RS-485 Options:</b>	
<p>1.2.5 Interval to Request Link Status:</p> <p><i>Indicates how often to send Data Link Layer status requests on a serial connection. This parameter is separate from the TCP Keep-alive timer.</i></p>	<input checked="" type="checkbox"/> Not Supported <input type="checkbox"/> Fixed at seconds <input type="checkbox"/> Configurable, range to seconds <input type="checkbox"/> Configurable, selectable from seconds <input type="checkbox"/> Configurable, other, describe	Not Supported	

<p>1.2.6 Supports DNP3 Collision Avoidance:</p> <p><i>Indicates whether an Outstation uses a collision avoidance algorithm.</i></p> <p><i>Collision avoidance may be implemented by a back-off timer with two parameters that define the back-off time range or by some other vendor-specific mechanism.</i></p> <p><i>The recommended back-off time is specified as being a fixed minimum delay plus a random delay, where the random delay has a maximum value specified. This defines a range of delay times that are randomly distributed between the minimum value and the minimum plus the maximum of the random value.</i></p> <p><i>If a back-off timer is implemented with only a fixed or only a random value, select the Back-off time method and set the parameter that is not supported to "Fixed at 0 ms".</i></p>	<input checked="" type="checkbox"/> No <input type="checkbox"/> Yes, using Back-off time = (Min + Random) method <input type="checkbox"/> Other, explain	No	
<p>1.2.7 Receiver Inter-character Timeout:</p> <p><i>When serial interfaces with asynchronous character framing are used, this parameter indicates if the receiver makes a check for gaps between characters. (i.e. extensions of the stop bit time of one character prior to the start bit of the following character within a message). If the receiver performs this check and the timeout is exceeded then the receiver discards the current data link frame. A receiver that does not discard data link frames on the basis of inter-character gaps is considered not to perform this check.</i></p> <p><i>Where no asynchronous serial interface is fitted this parameter is not applicable. In this case none of the options shall be selected.</i></p>	<input checked="" type="checkbox"/> Not Checked <input type="checkbox"/> No gap permitted <input type="checkbox"/> Fixed at bit times <input type="checkbox"/> Fixed at ms <input type="checkbox"/> Configurable, range to bit times <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from bit times <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	Not Checked	
<p>1.2.8 Inter-character gaps in transmission:</p> <p><i>When serial interfaces with asynchronous character framing are used, this parameter indicates whether extra delay is ever introduced between characters in the message, and if so, the maximum width of the gap.</i></p> <p><i>Where no asynchronous serial interface is fitted this parameter is not applicable. In this case none of the options shall be selected.</i></p>	<input checked="" type="checkbox"/> None (always transmits with no inter-character gap) <input type="checkbox"/> Maximum bit times <input type="checkbox"/> Maximum ms	None	

1.4 LINK LAYER	Capabilities	Current Value	If configurable list methods
<p>1.4.1 Data Link Address:</p> <p><i>Indicates if the link address is configurable over the entire valid range of 0 to 65,519. Data link addresses 0xFFFF0 through 0xFFFFF are reserved for broadcast or other special purposes.</i></p>	<input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range 0 to 65519 <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	0	
<p>1.4.2 DNP3 Source Address Validation:</p> <p><i>Indicates whether the Outstation will filter out requests not from a specific source address.</i></p>	<input type="checkbox"/> Never <input checked="" type="checkbox"/> Always, one address allowed (shown in 1.4.3) <input type="checkbox"/> Always, any one of multiple addresses allowed (each selectable as shown in 1.4.3) <input type="checkbox"/> Sometimes, explain	Always - single address	

1.4.3 DNP3 Source Address(es) expected when Validation is Enabled:  <i>Selects the allowed source address(es)</i>	<input type="checkbox"/> Configurable to any 16 bit DNP Data Link Address value <input checked="" type="checkbox"/> Configurable, range <b>0</b> to <b>65519</b> <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	0	
1.4.4 Self Address Support using address 0xFFFFC:  <i>If an Outstation receives a message with a destination address of 0xFFFFC it shall respond normally with its own source address. It must be possible to disable this feature if supported.</i>	<input type="checkbox"/> Yes (only allowed if configurable) <input checked="" type="checkbox"/> No	No	
1.4.5 Sends Confirmed User Data Frames:  <i>A list of conditions under which the device transmits confirmed link layer services (TEST_LINK_STATES, RESET_LINK_STATES, CONFIRMED_USER_DATA).</i>	<input checked="" type="checkbox"/> Never <input type="checkbox"/> Always <input type="checkbox"/> Sometimes, explain	Never	
1.4.6 Data Link Layer Confirmation Timeout:  <i>This timeout applies to any secondary data link message that requires a confirm or response (link reset, link status, user data, etc).</i>	<input checked="" type="checkbox"/> None <input type="checkbox"/> Fixed at ms <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	None	
1.4.7 Maximum Data Link Retries:  <i>The number of times the device will retransmit a frame that requests Link Layer confirmation.</i>	<input checked="" type="checkbox"/> None <input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	None	
1.4.8 Maximum number of octets Transmitted in a Data Link Frame:  <i>This number includes the CRCs. With a length field of 255, the maximum size would be 292.</i>	<input checked="" type="checkbox"/> Fixed at <b>292</b> <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	292	
1.4.9 Maximum number of octets that can be Received in a Data Link Frame:  <i>This number includes the CRCs. With a field length of 255, the maximum size would be 292. The device must be able to receive 292 octets to be compliant.</i>	<input checked="" type="checkbox"/> Fixed at <b>292</b> <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	292	

1.5 APPLICATION LAYER	Capabilities	Current Value	If configurable list methods
1.5.1 Maximum number of octets Transmitted in an Application Layer Fragment other than File Transfer:  <i>This size does not include any transport or frame octets. - Masters must provide a setting less than or equal to 249 to be compliant. - Outstations must provide a setting less than or equal to 2048 to be compliant.  Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 240.</i>	<input checked="" type="checkbox"/> Fixed at <b>0</b> <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	0	
1.5.2 Maximum number of octets Transmitted in an Application Layer Fragment containing File Transfer:	<input checked="" type="checkbox"/> Fixed at <b>0</b> <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	0	

<p>1.5.3 Maximum number of octets that can be received in an Application Layer Fragment:</p> <p><i>This size does not include any transport or frame octets.</i></p> <p><i>- Masters must provide a setting greater than or equal to 2048 to be compliant.</i></p> <p><i>- Outstations must provide a setting greater than or equal to 249 to be compliant.</i></p> <p><i>Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 241.</i></p>	<input checked="" type="checkbox"/> Fixed at <b>292</b> <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	292	
<p>1.5.4 Timeout waiting for Complete Application Layer Fragment:</p> <p><i>Timeout if all frames of a message fragment are not received in the specified time. Measured from time first frame of a fragment is received until the last frame is received.</i></p>	<input checked="" type="checkbox"/> None <input type="checkbox"/> Fixed at ms <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	None	
<p>1.5.5 Maximum number of objects allowed in a single control request for CROB (Group 12):</p> <p><i>Note: The current value of this outstation parameter is available remotely using protocol object Group 0 Variation 216.</i></p>	<input checked="" type="checkbox"/> Fixed at <b>0</b> (enter 0 if controls are not supported for CROB) <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input checked="" type="checkbox"/> Configurable, other, describe <b>The maximum allowed is limited by the maximum length of data link frame</b> <input type="checkbox"/> Variable, explain	0	
<p>1.5.6 Maximum number of objects allowed in a single control request for Analog Outputs (Group 41):</p>	<input checked="" type="checkbox"/> Fixed at <b>0</b> (enter 0 if controls are not supported for Analog Outputs) <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input checked="" type="checkbox"/> Configurable, other, describe <b>The maximum allowed is limited by the maximum length of data link frame</b> <input type="checkbox"/> Variable, explain	0	
<p>1.5.7 Maximum number of objects allowed in a single control request for Data Sets (Groups 85, 86, 87):</p>	<input checked="" type="checkbox"/> Fixed at <b>0</b> (enter 0 if controls are not supported for Data Sets) <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input checked="" type="checkbox"/> Configurable, other, describe <b>The maximum allowed is limited by the maximum length of data link frame</b> <input type="checkbox"/> Variable, explain	0	
<p>1.5.8 Supports mixed object groups (AOBs, CROBs and Data Sets) in the same control request:</p>	<input type="checkbox"/> Not applicable - controls are not supported <input checked="" type="checkbox"/> Yes <input type="checkbox"/> No	Yes	

<p>1.5.9 Control Status Codes Supported:</p> <p><i>Indicates which control status codes are supported by the device:</i></p> <ul style="list-style-type: none"> <li>- Masters must indicate which control status codes they accept in outstation responses.</li> <li>- Outstations must indicate which control status codes they generate in responses.</li> </ul> <p><i>Control status code 0 (success) must be supported by Masters and Outstations.</i></p>	<input type="checkbox"/> 1 - TIMEOUT <input type="checkbox"/> 2 - NO_SELECT <input type="checkbox"/> 3 - FORMAT_ERROR <input type="checkbox"/> 4 - NOT_SUPPORTED <input type="checkbox"/> 5 - ALREADY_ACTIVE <input type="checkbox"/> 6 - HARDWARE_ERROR <input type="checkbox"/> 7 - LOCAL <input type="checkbox"/> 8 - TOO_MANY_OBJS <input type="checkbox"/> 9 - NOT_AUTHORIZED <input type="checkbox"/> 10 - AUTOMATION_INHIBIT <input type="checkbox"/> 11 - PROCESSING_LIMITED <input type="checkbox"/> 12 - OUT_OF_RANGE <input type="checkbox"/> 13 - DOWNSTREAM_LOCAL <input type="checkbox"/> 14 - ALREADY_COMPLETE <input type="checkbox"/> 15 - BLOCKED <input type="checkbox"/> 16 - CANCELLED <input type="checkbox"/> 17 - BLOCKED_OTHER_MASTER <input type="checkbox"/> 18 - DOWNSTREAM_FAIL <input type="checkbox"/> 126 - RESERVED <input type="checkbox"/> 127 - UNDEFINED		
--	--	--	--

1.7 FILL OUT THE FOLLOWING ITEMS FOR OUTSTATIONS ONLY	Capabilities	Current Value	If configurable list methods
<p>1.7.1 Timeout waiting for Application Confirm of solicited response message:</p>	<input checked="" type="checkbox"/> None <input type="checkbox"/> Fixed at ms <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	None	
<p>1.7.2 How often is time synchronization required from the master:</p> <p><i>Details of when the master needs to perform a time synchronization to ensure that the outstation clock does not drift outside of an acceptable tolerance. If the option to relate this to IIN1.4 is used then details of when IIN1.4 is asserted are in section 1.10.2.</i></p>	<input type="checkbox"/> Never needs time <input checked="" type="checkbox"/> Within <b>180</b> seconds after IIN1.4 is set <input type="checkbox"/> Periodically, fixed at seconds <input type="checkbox"/> Periodically, between and seconds	Within 180 seconds of IIN1.4	
<p>1.7.3 Device Trouble Bit IIN1.6:</p> <p><i>If IIN1.6 device trouble bit is set under certain conditions, explain the possible causes.</i></p>	<input type="checkbox"/> Never used <input checked="" type="checkbox"/> Reason for setting <b>Hardware Problem</b>	Used as described	
<p>1.7.4 File Handle Timeout:</p> <p><i>If there is no activity referencing a file handle for a configurable length of time, the outstation must do an automatic close on the file. The timeout value must be configurable up to 1 hour. When this condition occurs the outstation will send a File Transport Status Object (obj grp 70 var 6) using a status code value of handle expired (0x02).</i></p>	<input checked="" type="checkbox"/> Not applicable, files not supported <input type="checkbox"/> Fixed at ms <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain	Not applicable	
<p>1.7.5 Event Buffer Overflow Behavior:</p>	<input checked="" type="checkbox"/> Discard the oldest event <input type="checkbox"/> Discard the newest event <input type="checkbox"/> Other, explain	Discard oldest	

<p>1.7.6 Event Buffer Organization:</p> <p><i>Explain how event buffers are arranged (per Object Group, per Class, single buffer, etc) and specify the number of events that can be buffered.</i></p>	<p><input checked="" type="checkbox"/> Per Object Group (see part 3)  <input type="checkbox"/> Per Class</p> <p>Class 1:  <input type="checkbox"/> Fixed at  <input type="checkbox"/> Configurable, range to  <input type="checkbox"/> Configurable, selectable from  <input type="checkbox"/> Configurable, other, describe</p> <p>Class 2:  <input type="checkbox"/> Fixed at  <input type="checkbox"/> Configurable, range to  <input type="checkbox"/> Configurable, selectable from  <input type="checkbox"/> Configurable, other, describe</p> <p>Class 3:  <input type="checkbox"/> Fixed at  <input type="checkbox"/> Configurable, range to  <input type="checkbox"/> Configurable, selectable from  <input type="checkbox"/> Configurable, other, describe</p> <p><input type="checkbox"/> Single Buffer  <input type="checkbox"/> Fixed at  <input type="checkbox"/> Configurable, range to  <input type="checkbox"/> Configurable, selectable from  <input type="checkbox"/> Configurable, other, describe</p> <p><input type="checkbox"/> Other, describe</p>	Per object group	
<p>1.7.7 Sends Multi-Fragment Responses:</p> <p><i>Indicates whether an Outstation sends multi-fragment responses (Masters do not send multi-fragment requests).</i></p>	<p><input checked="" type="checkbox"/> Yes  <input type="checkbox"/> No</p>	Yes	
<p>1.7.8 Last Fragment Confirmation:</p> <p><i>Indicates whether the Outstation requests confirmation of the last fragment of a multi-fragment response.</i></p>	<p><input type="checkbox"/> Always  <input checked="" type="checkbox"/> Sometimes, explain <b>Only when it contains events</b>  <input checked="" type="checkbox"/> Never</p>	Never	
<p>1.7.9 DNP Command Settings preserved through a device restart:</p> <p><i>If any of these settings are written through the DNP protocol and they are not preserved through a restart of the Outstation, the Master will have to write them again after it receives a response in which the Restart IIN bit is set.</i></p>	<p><input checked="" type="checkbox"/> Assign Class  <input checked="" type="checkbox"/> Analog Deadbands  <input checked="" type="checkbox"/> Data Set Prototypes  <input checked="" type="checkbox"/> Data Set Descriptors  <input type="checkbox"/> Function Code 31 Activate Configuration</p>		
<p>1.7.10 Supports configuration signature:</p> <p><i>Indicates whether an Outstation supports the Group 0 device attribute "Configuration signature" (variation 200). If yes, list the vendor-defined name(s) of the algorithm(s) available to calculate the signature.</i></p> <p><i>Note: The algorithm used for calculating the signature is identified by name in a string that can be determined remotely using protocol object Group 0 Variation 201. If only a single algorithm is available, identifying that algorithm in this object is optional.</i></p>	<p><input type="checkbox"/> Configuration signature supported</p> <p>If configuration signature is supported, then the following algorithm(s) are available for calculating the signature:</p>	Not Supported	

<p>1.7.11 Requests Application Confirmation:</p> <p><i>Indicate if application confirmation is requested:</i></p> <p>- when responding with events - when sending non-final fragments of multi-fragment responses</p> <p><i>Note: to be compliant both must be selected as "yes".</i></p>	<p>For event responses:</p> <p><input checked="" type="radio"/> Yes <input type="radio"/> No <input type="radio"/> Configurable</p> <p>For non-final fragments:</p> <p><input type="radio"/> Yes <input type="radio"/> No <input checked="" type="radio"/> Configurable</p>	<p>Event responses: Yes</p> <p>Non-final fragments: Yes</p>	
---	---	---	--

1.8 OUTSTATION UNSOLICITED RESPONSE SUPPORT	Capabilities	Current Value	If configurable list methods
<p>1.8.1 Supports Unsolicited Reporting:</p> <p><i>When the unsolicited response mode is configured "off", the device is to behave exactly like an equivalent device that has no support for unsolicited responses. If set to "on", the Outstation will send a null Unsolicited Response after it restarts, then wait for an Enable Unsolicited Response command from the master before sending additional Unsolicited Responses containing event data.</i></p>	<p><input type="checkbox"/> Yes <input type="checkbox"/> No <input checked="" type="checkbox"/> Configurable, selectable from On and Off</p>	<p>Off</p>	<p>protocol ----- --</p>
<p>1.8.2 Master Data Link Address:</p> <p><i>The destination address of the master device where the unsolicited responses will be sent.</i></p>	<p><input type="checkbox"/> Fixed at <input checked="" type="checkbox"/> Configurable, range <b>0 to 65519</b> <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe</p>	<p>0</p>	
<p>1.8.3 Unsolicited Response Confirmation Timeout:</p> <p><i>This is the amount of time that the outstation will wait for an Application Layer confirmation back from the master indicating that the master received the unsolicited response message. As a minimum, the range of configurable values must include times from one second to one minute. This parameter may be the same one that is used for normal, solicited, application confirmation timeouts, or it may be a separate parameter.</i></p>	<p><input checked="" type="checkbox"/> Fixed at <b>0ms</b> <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain</p>	<p>0 ms</p>	
<p>1.8.4 Number of Unsolicited Retries:</p> <p><i>This is the number of retries that an outstation transmits in each unsolicited response series if it does not receive confirmation back from the master. The configured value includes identical and regenerated retry messages. One of the choices must provide for an indefinite (and potentially infinite) number of transmissions.</i></p>	<p><input checked="" type="checkbox"/> None <input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Always infinite, never gives up</p>	<p>None</p>	

1.9 OUTSTATION UNSOLICITED RESPONSE TRIGGER CONDITIONS	Capabilities	Current Value	If configurable list methods
<p>1.9.1 Number of class 1 events:</p>	<p><input type="checkbox"/> Class 1 not used to trigger Unsolicited Responses <input checked="" type="checkbox"/> Fixed at <b>0</b> <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input checked="" type="checkbox"/> Configurable, other, describe <b>When exists an Class 1 configured, it always trigger Unsolicited Responses</b></p>	<p>0</p>	

1.9.2 Number of class 2 events:	<input type="checkbox"/> Class 2 not used to trigger Unsolicited Responses <input checked="" type="checkbox"/> Fixed at <b>0</b> <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input checked="" type="checkbox"/> Configurable, other, describe <b>When exists an Class 2 configured, it always trigger Unsolicited Responses</b>	0	
1.9.3 Number of class 3 events:	<input type="checkbox"/> Class 3 not used to trigger Unsolicited Responses <input checked="" type="checkbox"/> Fixed at <b>0</b> <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input checked="" type="checkbox"/> Configurable, other, describe <b>When exists an Class 3 configured, it always trigger Unsolicited Responses</b>	0	
1.9.4 Total number of events from any class:	<input type="checkbox"/> Total Number of Events not used to trigger Unsolicited Responses <input checked="" type="checkbox"/> Fixed at <b>100</b> <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	100	
1.9.5 Hold time after class 1 event: <i>A configurable value of 0 indicates that responses are not delayed due to this parameter.</i>	<input type="checkbox"/> Class 1 not used to trigger Unsolicited Responses <input checked="" type="checkbox"/> Fixed at <b>0ms</b> <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe	0 ms	
1.9.6 Hold time after class 2 event: <i>A configurable value of 0 indicates that responses are not delayed due to this parameter.</i>	<input type="checkbox"/> Class 2 not used to trigger Unsolicited Responses <input checked="" type="checkbox"/> Fixed at <b>0ms</b> <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe	0 ms	
1.9.7 Hold time after class 3 event: <i>A configurable value of 0 indicates that responses are not delayed due to this parameter.</i>	<input type="checkbox"/> Class 3 not used to trigger Unsolicited Responses <input checked="" type="checkbox"/> Fixed at <b>0ms</b> <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe	0 ms	
1.9.8 Hold time after event assigned to any class: <i>A configurable value of 0 indicates that responses are not delayed due to this parameter.</i>	<input type="checkbox"/> Class events not used to trigger Unsolicited Responses <input checked="" type="checkbox"/> Fixed at <b>0ms</b> <input type="checkbox"/> Configurable, range to ms <input type="checkbox"/> Configurable, selectable from ms <input type="checkbox"/> Configurable, other, describe	0 ms	
1.9.9 Retrigger Hold Time: <i>The hold-time timer may be retriggered for each new event detected (increased possibility of capturing all the changes in a single response) or not retriggered (giving the master a guaranteed update time).</i>	<input type="checkbox"/> Hold-time timer will be retriggered for each new event detected (may get more changes in next response) <input checked="" type="checkbox"/> Hold-time timer will not be retriggered for each new event detected (guaranteed update time)	Not retriggered	
1.9.10 Other Unsolicited Response Trigger Conditions:	<input checked="" type="checkbox"/> <b>Change of Data</b>	Other, <b>Change of Data</b>	

1.10 OUTSTATION PERFORMANCE	Capabilities	Current Value	If configurable list methods
1.10.1 Maximum Time Base Drift (milliseconds per minute): <i>If the device is synchronized by DNP, what is the clock drift rate over the full operating temperature range.</i>	<input checked="" type="checkbox"/> Fixed at <b>1ms</b> <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	1 ms	

1.10.2 When does outstation set IIN1.4:  <i>When does the outstation set the internal indication IIN1.4 NEED_TIME</i>	<input type="checkbox"/> Never <input type="checkbox"/> Asserted at startup until first Time Synchronization request received <input type="checkbox"/> Periodically every seconds <input checked="" type="checkbox"/> Periodically, range 1 to <b>65535</b> seconds <input type="checkbox"/> Periodically, selectable from seconds <input type="checkbox"/> seconds after last time sync <input type="checkbox"/> Range to seconds after last time sync <input type="checkbox"/> Selectable from seconds after last time sync <input type="checkbox"/> When time error may have drifted by ms <input type="checkbox"/> When time error may have drifted by range to ms <input type="checkbox"/> When time error may have drifted by selectable from ms		
1.10.3 Maximum Internal Time Reference Error when set via DNP (ms):  <i>The difference between the time set in DNP Write Time message, and the time actually set in the outstation.</i>	<input checked="" type="checkbox"/> Fixed at <b>1ms</b> <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	1 ms	
1.10.4 Maximum Delay Measurement Error (ms):  <i>The difference between the time reported in the delay measurement response and the actual time between receipt of the delay measurement request and issuing the delay measurement reply.</i>	<input checked="" type="checkbox"/> Fixed at <b>1ms</b> <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	1 ms	
1.10.5 Maximum Response Time (ms):  <i>The amount of time an outstation will take to respond upon receipt of a valid request. This does not include the message transmission time.</i>	<input checked="" type="checkbox"/> Fixed at <b>100ms</b> <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	100 ms	
1.10.6 Maximum time from start-up to IIN 1.4 assertion (ms):	<input checked="" type="checkbox"/> Fixed at <b>1ms</b> <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	1 ms	
1.10.7 Maximum Event Time-tag error for local Binary and Double Bit I/O (ms):  <i>The error between the time-tag reported and the absolute time of the physical event. This error includes the Internal Time Reference Error. Note: The current value of this parameter is available remotely using protocol object Group 0 Variation 217.</i>	<input checked="" type="checkbox"/> Fixed at <b>150ms</b> <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	150 ms	
1.10.8 Maximum Event Time-tag error for local I/O other than Binary and Double Bit data types (ms):	<input checked="" type="checkbox"/> Fixed at <b>150ms</b> <input type="checkbox"/> Range to ms <input type="checkbox"/> Selectable from ms <input type="checkbox"/> Other, describe	150 ms	

1.11 INDIVIDUAL FIELD OUTSTATION PARAMETERS	Value of Current Setting	If configurable list methods
1.11.1 User-assigned location name or code string (same as g0v245):		
1.11.2 User-assigned ID code/number string (same as g0v246):		
1.11.3 User-assigned name string for the outstation (same as g0v247):		
1.11.4 Device Serial Number string (same as g0v248):		

1.13 BROADCAST FUNCTIONALITY	Capabilities	Current Value	If configurable list methods
This section indicates which functions are supported by the device when using broadcast addresses.			
Note that this section shows only entries that may have a meaningful purpose when used with broadcast requests.			

1.13.1 Support for broadcast functionality:	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled <input type="radio"/> Configurable	Enabled	
1.13.2 Write functions (FC = 2) supported with broadcast requests:	<p>Write clock (g50v1 with qualifier code 07)</p> <input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Write clock: Enabled	Clock: Time: Restart: Other:
	<p>Write last recorded time (g50v3 with qualifier code 07)</p> <input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Write last recorded time: Enabled	
	<p>Clear restart (g80v1 with qualifier code 00 and index = 7, value = 0)</p> <input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Clear restart: Enabled	
	<p>Write to any other group / variation / qualifier code</p> <input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Write any other: Enabled	
1.13.3 Direct operate functions (FC = 5) supported with broadcast requests:	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Enabled	
1.13.4 Direct operate, no acknowledgement functions (FC = 6) supported with broadcast requests:	<input type="radio"/> Disabled <input type="radio"/> Enabled <input checked="" type="radio"/> Configurable, other (described elsewhere)	Enabled	
1.13.5 Immediate freeze functions (FC = 7) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.6 Immediate freeze, no acknowledgement functions (FC = 8) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.7 Freeze and clear functions (FC = 9) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.8 Freeze and clear, no acknowledgement functions (FC = 10) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.9 Freeze at time functions (FC = 11) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.10 Freeze at time, no acknowledgement functions (FC = 12) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.11 Cold restart functions (FC = 13) supported with broadcast requests:	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Enabled	
1.13.12 Warm restart functions (FC = 14) supported with broadcast requests:	<input type="radio"/> Disabled <input checked="" type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Enabled	
1.13.13 Initialize data functions (FC = 15) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.14 Initialize application functions (FC = 16) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.15 Start application functions (FC = 17) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	

1.13.16 Stop application functions (FC = 18) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.17 Save configuration functions (FC = 19) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.18 Enable unsolicited functions (FC = 20) supported with broadcast requests:	Enable unsolicited by event Class (g60v2, g60v3 and g60v4 with qualifier code 06) <input type="radio"/> Disabled <input checked="" type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)  Enable unsolicited for any other group / variation / qualifier code <input type="radio"/> Disabled <input checked="" type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	By event class: Enabled  By any other: Enabled	Class: Other:
1.13.19 Disable unsolicited functions (FC = 21) supported with broadcast requests:	Disable unsolicited by event Class (g60v2, g60v3 and g60v4 with qualifier code 06) <input type="radio"/> Disabled <input checked="" type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)  Disable unsolicited for any other group / variation / qualifier code <input type="radio"/> Disabled <input checked="" type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	By event class: Enabled  By any other: Enabled	Class: Other:
1.13.20 Assign class functions (FC = 22) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.21 Record current time functions (FC = 24) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	
1.13.22 Activate configuration functions (FC = 31) supported with broadcast requests:	<input checked="" type="radio"/> Disabled <input type="radio"/> Enabled <input type="radio"/> Configurable, other (described elsewhere)	Disabled	

## 2 Mapping between DNP3 and IEC 61850 Objects

This optional section allows each configuration parameter or point in the DNP Data map to be tied to an attribute in the IEC 61850 object models (and vice-versa).

Earlier versions of this section (up to version 2.07) used mappings based on an "access point" (section 2.1.1 and then a series of XPath references (section 2.1.2). Section 2.1.2 has been superseded in version 2.08 onwards with mappings defined using either predefined rules (section 2.1.3) or specified as an equation (section 2.1.4). The list of pre-defined rules is found in the IEEE 1815-1 document.

The following display has been selected to be in a tabular form.

### MAPPING BETWEEN DNP3 AND IEC 61850 OBJECTS

## 3 Capabilities and Current Settings for Device Database (Outstation only)

The following tables identify the capabilities and current settings for each DNP3 data type. Details defining the data points available in the device are shown in part 5 of this Device Profile.

### 3.1 BINARY INPUTS

Static (Steady-State) Object Number: 1

Event Object Number: 2

	Capabilities (leave tick-boxes blank if this data type is not supported)	Current Value	If configurable list methods
3.1.1 Static Variation reported when variation 0 requested or in response to Class polls:	<input checked="" type="checkbox"/> Variation 1 - packed format <input type="checkbox"/> Variation 2 - with flag <input type="checkbox"/> Based on point index (add column to table in part 5)	One	
3.1.2 Event Variation reported when variation 0 requested or in response to Class polls:  <i>Note: The support for binary input events can be determined remotely using protocol object Group 0 Variation 237.</i>	<input type="checkbox"/> Variation 1 - without time <input checked="" type="checkbox"/> Variation 2 - with absolute time <input type="checkbox"/> Variation 3 - with relative time <input type="checkbox"/> Based on point index (add column to table in part 5)	Two	
3.1.3 Event reporting mode:  <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. "All events" must be checked to be compliant.</i>	<input type="checkbox"/> Only most recent <input checked="" type="checkbox"/> All events <input type="checkbox"/> Based on point index (add column to table in part 5)	All events	
3.1.4 Binary Inputs included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	
3.1.5 Binary Inputs Event Buffer Organization:  <i>When event buffers are allocated per object group (see part 1.7.6), indicate the number of events that can be buffered for Binary Inputs. If event buffers are not allocated per object group then set "Fixed at 0".</i>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Number of events =	

**3.3 BINARY OUTPUT STATUS AND CONTROL RELAY OUTPUT BLOCK**  
**Binary Output Status Object Number: 10**  
**Binary Output Event Object Number: 11**  
**CROB Object Number: 12**  
**Binary Output Command Event Object Number: 13**

	Capabilities (leave tick-boxes blank if this data type is not supported)	Current Value	If configurable list methods
3.3.1 Minimum pulse time allowed with Trip, Close and Pulse On commands:	<input checked="" type="checkbox"/> Fixed at <b>0</b> ms (hardware may limit this further) <input type="checkbox"/> Based on point index (add column to table in part 5)	Fixed at 0 ms	
3.3.2 Maximum pulse time allowed with Trip, Close and Pulse On commands:	<input checked="" type="checkbox"/> Fixed at <b>100</b> ms (hardware may limit this further) <input type="checkbox"/> Based on point index (add column to table in part 5)	Fixed at 100 ms	
3.3.3 Binary Output Status included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.3.4 Reports Output Command Event Objects:	<input type="checkbox"/> Never <input type="checkbox"/> Only upon a successful Control <input type="checkbox"/> Upon all control attempts		
3.3.5 Static Variation reported when variation 0 requested or in response to Class polls:	<input type="checkbox"/> Variation 1 - packed format <input type="checkbox"/> Variation 2 - output status with flags <input type="checkbox"/> Based on point index (add column to table in part 5)		

3.3.6 Event Variation reported when variation 0 requested or in response to Class polls:  <i>Note: The support for binary output events can be determined remotely using protocol object Group 0 Variation 222.</i>	<input type="checkbox"/> Variation 1 - status without time <input type="checkbox"/> Variation 2 - status with time <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.3.7 Command Event Variation reported when variation 0 requested or in response to Class polls:	<input type="checkbox"/> Variation 1 - command status without time <input type="checkbox"/> Variation 2 - command status with time <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.3.8 Event reporting mode:  <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event.</i>	<input type="checkbox"/> Only most recent <input type="checkbox"/> All events		
3.3.9 Command Event reporting mode:  <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event.</i>	<input type="checkbox"/> Only most recent <input type="checkbox"/> All events		
3.3.10 Maximum Time between Select and Operate:	<input checked="" type="checkbox"/> Not Applicable <input type="checkbox"/> Fixed at seconds <input type="checkbox"/> Configurable, range to seconds <input type="checkbox"/> Configurable, selectable from seconds <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain <input type="checkbox"/> Based on point index (add column to table in part 5)	Not Applicable	
3.3.11 Binary Outputs Event Buffer Organization:  <i>When event buffers are allocated per object group (see part 1.7.6), indicate the number of events that can be buffered for Binary Outputs. If event buffers are not allocated per object group then set "Fixed at 0".</i>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Number of events =	
3.3.12 Binary Output Commands Event Buffer Organization:  <i>When event buffers are allocated per object group (see part 1.7.6), indicate the number of events that can be buffered for Binary Output Commands. If event buffers are not allocated per object group then set "Fixed at 0".</i>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Number of events =	

<b>3.4 COUNTERS / FROZEN COUNTERS</b>			
<b>Counter Group Number: 20</b>			
<b>Frozen Counter Group Number: 21</b>			
<b>Counter Event Group Number: 22</b>			
<b>Frozen Counter Event Group Number: 23</b>			
	<b>Capabilities (leave tick-boxes blank if this data type is not supported)</b>	<b>Current Value</b>	<b>If configurable list methods</b>
3.4.1 Static Counter Variation reported when variation 0 requested or in response to Class polls:	<input type="checkbox"/> Variation 1 - 32-bit with flag <input type="checkbox"/> Variation 2 - 16-bit with flag <input checked="" type="checkbox"/> Variation 5 - 32-bit without flag <input type="checkbox"/> Variation 6 - 16-bit without flag <input type="checkbox"/> Based on point index (add column to table in part 5)	Five	
3.4.2 Counter Event Variation reported when variation 0 requested or in response to Class polls:  <i>Note: The support for counter events can be determined remotely using protocol object Group 0 Variation 227.</i>	<input type="checkbox"/> Variation 1 - 32-bit with flag <input type="checkbox"/> Variation 2 - 16-bit with flag <input checked="" type="checkbox"/> Variation 5 - 32-bit with flag and time <input type="checkbox"/> Variation 6 - 16-bit with flag and time <input type="checkbox"/> Based on point index (add column to table in part 5)	Five	

3.4.3 Counters included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	
3.4.4 Counter Event reporting mode:  <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. Only the most recent event is typically reported for Counters. When reporting only the most recent event the counter value returned in the response may be either the value at the time that the event is queued or it may be the value at the time of the response.</i>	<input type="checkbox"/> A: Only most recent (value at time of event) <input type="checkbox"/> B: Only most recent (value at time of response) <input checked="" type="checkbox"/> C: All events <input type="checkbox"/> Based on point index (add column to table in part 5)	All events	
3.4.5 Static Frozen Counter Variation reported when variation 0 requested or in response to Class polls:	<input type="checkbox"/> Variation 1 - 32-bit with flag <input type="checkbox"/> Variation 2 - 16-bit with flag <input type="checkbox"/> Variation 5 - 32-bit with flag and time <input type="checkbox"/> Variation 6 - 16-bit with flag and time <input type="checkbox"/> Variation 9 - 32-bit without flag <input type="checkbox"/> Variation 10 - 16-bit without flag <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.4.6 Frozen Counter Event Variation reported when variation 0 requested or in response to Class polls:  <i>Note: The support for frozen counter events can be determined remotely using protocol object Group 0 Variation 225.</i>	<input type="checkbox"/> Variation 1 - 32-bit with flag <input type="checkbox"/> Variation 2 - 16-bit with flag <input type="checkbox"/> Variation 5 - 32-bit without flag <input type="checkbox"/> Variation 6 - 16-bit without flag <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.4.7 Frozen Counters included in Class 0 response:	<input type="checkbox"/> Always <input type="checkbox"/> Never <input type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.4.8 Frozen Counter Event reporting mode:  <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. All events are typically reported for Frozen Counters</i>	<input type="checkbox"/> Only most recent frozen value <input type="checkbox"/> All frozen values <input type="checkbox"/> Based on point index (add column to table in part 5)		
3.4.9 Counters Roll Over at:	<input type="checkbox"/> 16 Bits (65,535) <input checked="" type="checkbox"/> 32 Bits (4,294,967,295) <input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Based on point index (add column to table in part 5)	4,294,967,295	
3.4.10 Counters frozen by means of:	<input type="checkbox"/> Master Request <input type="checkbox"/> Freezes itself without concern for time of day <input type="checkbox"/> Freezes itself and requires time of day <input checked="" type="checkbox"/> Other, explain: <b>Not applicable</b>	Other	
3.4.11 Counters Event Buffer Organization:  <i>When event buffers are allocated per object group (see part 1.7.6), indicate the number of events that can be buffered for Counters. If event buffers are not allocated per object group then set "Fixed at 0".</i>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Number of events =	

<p>3.4.12 Frozen Counters Event Buffer Organization:</p> <p><i>When event buffers are allocated per object group (see part 1.7.6), indicate the number of events that can be buffered for Frozen Counters. If event buffers are not allocated per object group then set "Fixed at 0".</i></p>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Number of events =	
<p>3.4.13 Reports counter events for change of value:</p> <p><i>Indicate if counter events are created when the counter value changes.</i></p>	<input type="checkbox"/> Yes for all counters <input type="checkbox"/> No for all counters <input type="checkbox"/> Based on point index (add column to table in part 5)		

**3.5 ANALOG INPUTS**  
**Static (Steady-State) Object Number: 30**  
**Event Object Number: 32**  
**Deadband Object Number: 34**

	<b>Capabilities (leave tick-boxes blank if this data type is not supported)</b>	<b>Current Value</b>	<b>If configurable list methods</b>
<p>3.5.1 Static Variation reported when variation 0 requested or in response to Class polls:</p>	<input type="checkbox"/> Variation 1 - 32-bit with flag <input type="checkbox"/> Variation 2 - 16-bit with flag <input checked="" type="checkbox"/> Variation 3 - 32-bit without flag <input type="checkbox"/> Variation 4 - 16-bit without flag <input type="checkbox"/> Variation 5 - single-precision floating point with flag <input type="checkbox"/> Variation 6 - double-precision floating point with flag <input type="checkbox"/> Based on point index (add column to table in part 5)	Three	
<p>3.5.2 Event Variation reported when variation 0 requested or in response to Class polls:</p> <p><i>Note: The support for analog input events can be determined remotely using protocol object Group 0 Variation 231.</i></p>	<input type="checkbox"/> Variation 1 - 32-bit without time <input type="checkbox"/> Variation 2 - 16-bit without time <input checked="" type="checkbox"/> Variation 3 - 32-bit with time <input type="checkbox"/> Variation 4 - 16-bit with time <input type="checkbox"/> Variation 5 - single-precision floating point w/o time <input type="checkbox"/> Variation 6 - double-precision floating point w/o time <input type="checkbox"/> Variation 7 - single-precision floating point with time <input type="checkbox"/> Variation 8 - double-precision floating point with time <input type="checkbox"/> Based on point index (add column to table in part 5)	Three	
<p>3.5.3 Event reporting mode:</p> <p><i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. Only the most recent event is typically reported for Analog Inputs. When reporting only the most recent event the analog value returned in the response may be either the value at the time that the event is queued or it may be the value at the time of the response.</i></p>	<input type="checkbox"/> A: Only most recent (value at time of event) <input type="checkbox"/> B: Only most recent (value at time of response) <input checked="" type="checkbox"/> C: All events <input type="checkbox"/> Based on point index (add column to table in part 5)	All events	
<p>3.5.4 Analog Inputs included in Class 0 response:</p>	<input type="checkbox"/> Always <input type="checkbox"/> Never <input checked="" type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	If assigned	

<p>3.5.5 How Deadbands are set:</p>	<input type="checkbox"/> A. Global Fixed <input type="checkbox"/> B. Configurable through DNP <input checked="" type="checkbox"/> C. Configurable via other means <input type="checkbox"/> D. Other, explain:  <input type="checkbox"/> Based on point index - column in part 5 specifies which of the options applies, B, C, or D	C	software <b>CTR3Comm</b> <b>Vers 1.00</b> ----- --
<p>3.5.6 Analog Deadband Algorithm:</p> <p>simple- just compares the difference from the previous reported value</p> <p>integrating- keeps track of the accumulated change</p> <p>other- indicating another algorithm</p>	<input checked="" type="checkbox"/> Simple <input type="checkbox"/> Integrating <input type="checkbox"/> Other, explain: <input type="checkbox"/> Based on point index (add column to table in part 5)	Simple	
<p>3.5.7 Static Frozen Analog Input Variation reported when variation 0 requested or in response to Class polls:</p>	<input type="checkbox"/> Variation 1 - 32-bit with flag <input type="checkbox"/> Variation 2 - 16-bit with flag <input type="checkbox"/> Variation 3 - 32-bit with time-of-freeze <input type="checkbox"/> Variation 4 - 16-bit with time-of-freeze <input type="checkbox"/> Variation 5 - 32-bit without flag <input type="checkbox"/> Variation 6 - 16-bit without flag <input type="checkbox"/> Variation 7 - single-precision floating point with flag <input type="checkbox"/> Variation 8 - double-precision floating point with flag <input type="checkbox"/> Based on point index (add column to table in part 5)		
<p>3.5.8 Frozen Analog Input Event Variation reported when variation 0 requested or in response to Class polls:</p> <p><i>Note: The support for frozen analog input events can be determined remotely using protocol object Group 0 Variation 230.</i></p>	<input type="checkbox"/> Variation 1 - 32-bit without time <input type="checkbox"/> Variation 2 - 16-bit without time <input type="checkbox"/> Variation 3 - 32-bit with time <input type="checkbox"/> Variation 4 - 16-bit with time <input type="checkbox"/> Variation 5 - single-precision floating point w/o time <input type="checkbox"/> Variation 6 - double-precision floating point w/o time <input type="checkbox"/> Variation 7 - single-precision floating point with time <input type="checkbox"/> Variation 8 - double-precision floating point with time <input type="checkbox"/> Based on point index (add column to table in part 5)		
<p>3.5.9 Frozen Analog Inputs included in Class 0 response:</p>	<input type="checkbox"/> Always <input type="checkbox"/> Never <input type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)		
<p>3.5.10 Frozen Analog Input Event reporting mode:</p> <p><i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event. All events are typically reported for Frozen Analog Inputs.</i></p>	<input type="checkbox"/> Only most recent frozen value <input type="checkbox"/> All frozen values <input type="checkbox"/> Based on point index (add column to table in part 5)		
<p>3.5.11 Analog Inputs Event Buffer Organization:</p> <p><i>When event buffers are allocated per object group (see part 1.7.6), indicate the number of events that can be buffered for Analog Inputs. If event buffers are not allocated per object group then set "Fixed at 0".</i></p>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Number of events =	

<p>3.5.12 Frozen Analog Inputs Event Buffer Organization:</p> <p><i>When event buffers are allocated per object group (see part 1.7.6), indicate the number of events that can be buffered for Frozen Analog Inputs. If event buffers are not allocated per object group then set "Fixed at 0".</i></p>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Number of events =	
---	--	--------------------	--

**3.6 ANALOG OUTPUTS AND ANALOG OUTPUT COMMANDS**  
**Analog Output Status Group Number: 40**  
**Analog Outputs Group Number: 41**  
**Analog Output Events Group Number: 42**  
**Analog Output Command Events Group Number: 43**

	<b>Capabilities (leave tick-boxes blank if this data type is not supported)</b>	<b>Current Value</b>	<b>If configurable list methods</b>
<p>3.6.1 Static Analog Output Status Variation reported when variation 0 requested or in response to Class polls:</p>	<input checked="" type="checkbox"/> Variation 1 - 32-bit with flag <input type="checkbox"/> Variation 2 - 16-bit with flag <input type="checkbox"/> Variation 3 - single-precision floating point with flag <input type="checkbox"/> Variation 4 - double-precision floating point with flag <input type="checkbox"/> Based on point index (add column to table in part 5)	One	
<p>3.6.2 Analog Output Status included in Class 0 response:</p>	<input type="checkbox"/> Always <input checked="" type="checkbox"/> Never <input type="checkbox"/> Only if point is assigned to a class <input type="checkbox"/> Based on point index (add column to table in part 5)	Never	
<p>3.6.3 Reports Output Command Event Objects:</p>	<input checked="" type="checkbox"/> Never <input type="checkbox"/> Only upon a successful Control <input type="checkbox"/> Upon all control attempts	Never	
<p>3.6.4 Event Variation reported when variation 0 requested or in response to Class polls:</p> <p><i>Note: The support for analog output events can be determined remotely using protocol object Group 0 Variation 219.</i></p>	<input type="checkbox"/> Variation 1 - 32-bit without time <input type="checkbox"/> Variation 2 - 16-bit without time <input type="checkbox"/> Variation 3 - 32-bit with time <input type="checkbox"/> Variation 4 - 16-bit with time <input type="checkbox"/> Variation 5 - single-precision floating point w/o time <input type="checkbox"/> Variation 6 - double-precision floating point w/o time <input type="checkbox"/> Variation 7 - single-precision floating point with time <input type="checkbox"/> Variation 8 - double-precision floating point with time <input type="checkbox"/> Based on point index (add column to table in part 5)		
<p>3.6.5 Command Event Variation reported when variation 0 requested or in response to Class polls:</p>	<input type="checkbox"/> Variation 1 - 32-bit without time <input type="checkbox"/> Variation 2 - 16-bit without time <input type="checkbox"/> Variation 3 - 32-bit with time <input type="checkbox"/> Variation 4 - 16-bit with time <input type="checkbox"/> Variation 5 - single-precision floating point w/o time <input type="checkbox"/> Variation 6 - double-precision floating point w/o time <input type="checkbox"/> Variation 7 - single-precision floating point with time <input type="checkbox"/> Variation 8 - double-precision floating point with time <input type="checkbox"/> Based on point index (add column to table in part 5)		

3.6.6 Event reporting mode:  <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event.</i>	<input type="checkbox"/> Only most recent <input type="checkbox"/> All events		
3.6.7 Command Event reporting mode:  <i>When responding with event data and more than one event has occurred for a data point, an Outstation may include all events or only the most recent event.</i>	<input type="checkbox"/> Only most recent <input type="checkbox"/> All events		
3.6.8 Maximum Time between Select and Operate:	<input checked="" type="checkbox"/> Not Applicable <input type="checkbox"/> Fixed at seconds <input type="checkbox"/> Configurable, range to seconds <input type="checkbox"/> Configurable, selectable from seconds <input type="checkbox"/> Configurable, other, describe <input type="checkbox"/> Variable, explain <input type="checkbox"/> Based on point index (add column to table in part 5)	Not Applicable	
3.6.9 Analog Outputs Event Buffer Organization:  <i>When event buffers are allocated per object group (see part 1.7.6), indicate the number of events that can be buffered for Analog Outputs. If event buffers are not allocated per object group then set "Fixed at 0".</i>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Number of events =	
3.6.10 Analog Output Commands Event Buffer Organization:  <i>When event buffers are allocated per object group (see part 1.7.6), indicate the number of events that can be buffered for Analog Output Commands. If event buffers are not allocated per object group then set "Fixed at 0".</i>	<input type="checkbox"/> Fixed at <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	Number of events =	

<b>3.7 FILE CONTROL</b>			
<b>Object Number: 70</b>			
	<b>Capabilities</b>	<b>Current Value</b>	<b>If configurable list methods</b>
3.7.1 File Transfer Supported:	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No (set 3.7.6 to "Fixed at 0" and do not complete other entries in section 3.7)	No	
3.7.2 File Authentication:  <i>Indicates whether a valid authentication key must be obtained prior to open and delete requests.</i>	<input type="checkbox"/> Always <input type="checkbox"/> Sometimes, explain <input checked="" type="checkbox"/> Never	Never	
3.7.3 File Append Mode:  <i>Indicates if a file can be opened and appended to versus just overwritten.</i>	<input type="checkbox"/> Always <input type="checkbox"/> Sometimes, explain <input checked="" type="checkbox"/> Never	Never	
3.7.4 Permissions Support:  <i>Indicates the device is capable of using the indicated permissions.</i>	<input type="checkbox"/> Owner Read Allowed: 0x0100 <input type="checkbox"/> Owner Write Allowed: 0x0080 <input type="checkbox"/> Owner Execute Allowed: 0x0040 <input type="checkbox"/> Group Read Allowed: 0x0020 <input type="checkbox"/> Group Write Allowed: 0x0010 <input type="checkbox"/> Group Execute Allowed: 0x0008 <input type="checkbox"/> World Read Allowed: 0x0004 <input type="checkbox"/> World Write Allowed: 0x0002 <input type="checkbox"/> World Execute Allowed: 0x0001		

3.7.5 Multiple Blocks in a Fragment:  <i>File data is transferred in a series of blocks of a maximum specified size. This indicates whether only a single block or multiple blocks will be sent in fragment.</i>	<input type="checkbox"/> Yes <input checked="" type="checkbox"/> No	No	
3.7.6 Max number of Files Open at one time:	<input checked="" type="checkbox"/> Fixed at 0 <input type="checkbox"/> Configurable, range to <input type="checkbox"/> Configurable, selectable from <input type="checkbox"/> Configurable, other, describe	0	

<b>3.10 DATA SET PROTOTYPE</b> <b>Object Number: 85</b> <b>Variation Number: 1</b>			
	<b>Capabilities</b>	<b>Current Value</b>	<b>If configurable list methods</b>

This version of the Device Profile has no requirement for describing Data Set Prototype capabilities and current settings. This page is intentionally left blank, existing as placeholder for future use.

<b>3.11 DATA SET DESCRIPTOR CONTENTS AND CHARACTERISTICS</b> <b>Object Number: 86</b> <b>Variation Numbers: 1 and 2</b>			
---	--	--	--

This version of the Device Profile has no requirement for describing Data Set Descriptor capabilities and current settings. This page is intentionally left blank, existing as placeholder for future use.

## 4 Implementation Table

The following implementation table identifies which object group and variations, function codes and qualifiers the device supports in both requests and responses. The Request columns identify all requests that may be sent by a Master, or all request that must be parsed by a Outstation. The Response columns identify all responses that must be parsed by a Master, or all responses that may be sent by a Outstation.

DNP OBJECT GROUP & VARIATION			REQUEST Master may issue Outstation must parse		RESPONSE Master must parse Outstation may issue	
Object Group Number	Variation Number	Description	Function Codes (dec)	Qualifier Codes (hex)	Function Codes (dec)	Qualifier Codes (hex)
1	0	Binary Input - any variation	1( <i>read</i> )	00, 01 ( <i>start-stop</i> ), 06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )		
1	1	Binary Input - Single-bit packed	1( <i>read</i> )	00, 01 ( <i>start-stop</i> ), 06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	129 ( <i>Response</i> )	00, 01 ( <i>start-stop</i> )
1	2	Binary Input - Single-bit with flag	1( <i>read</i> )	00, 01 ( <i>start-stop</i> ), 06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	129 ( <i>Response</i> )	00, 01 ( <i>start-stop</i> )
2	0	Binary Input Change Event- any variation	1( <i>read</i> )	06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )		
2	1	Binary Input Change Event- without time	1( <i>read</i> )	06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	129 ( <i>Response</i> )	17, 28 ( <i>index</i> )
2	1	Binary Input Change Event- without time	1( <i>read</i> )	06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	130 ( <i>Unsol. Resp</i> )	17, 28 ( <i>index</i> )
2	2	Binary Input Change Event- with absolute time	1( <i>read</i> )	06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	129 ( <i>Response</i> )	17, 28 ( <i>index</i> )
2	2	Binary Input Change Event- with absolute time	1( <i>read</i> )	06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	130 ( <i>Unsol. Resp</i> )	17, 28 ( <i>index</i> )
12	1	Binary Output Command (CROB) - control relay output block	3 ( <i>select</i> )	17, 28 ( <i>index</i> )	129 ( <i>Response</i> )	echo of request
12	1	Binary Output Command (CROB) - control relay output block	4 ( <i>operate</i> )	17, 28 ( <i>index</i> )	129 ( <i>Response</i> )	echo of request
12	1	Binary Output Command (CROB) - control relay output block	5 ( <i>direct op.</i> )	17, 28 ( <i>index</i> )	129 ( <i>Response</i> )	echo of request
12	1	Binary Output Command (CROB) - control relay output block	6 ( <i>direct op, no ack</i> )	17, 28 ( <i>index</i> )	129 ( <i>Response</i> )	echo of request
20	0	Counter - any variation	1( <i>read</i> )	00, 01 ( <i>start-stop</i> ), 06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )		
20	5	Counter - 32-bit without flag	1( <i>read</i> )	00, 01 ( <i>start-stop</i> ), 06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	129 ( <i>Response</i> )	00 ( <i>start-stop</i> )
22	5	Counter Change Event - 32-bit with flag and time	1( <i>read</i> )	06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	129 ( <i>Response</i> )	17, 28 ( <i>index</i> )
30	0	Analog Input - any variation	1( <i>read</i> )	00, 01 ( <i>start-stop</i> ), 06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )		
30	1	Analog Input - 32-bit with flag	1( <i>read</i> )	00, 01 ( <i>start-stop</i> ), 06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	129 ( <i>Response</i> )	00 ( <i>start-stop</i> )
30	2	Analog Input - 16-bit with flag	1( <i>read</i> )	00, 01 ( <i>start-stop</i> ), 06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	129 ( <i>Response</i> )	00 ( <i>start-stop</i> )
30	3	Analog Input - 32-bit without flag	1( <i>read</i> )	00, 01 ( <i>start-stop</i> ), 06 ( <i>no range, or all</i> ), 07, 08 ( <i>limited qty</i> )	129 ( <i>Response</i> )	00 ( <i>start-stop</i> )

30	4	Analog Input - 16-bit without flag	1(read)	00, 01 (start-stop), 06 (no range, or all), 07, 08 (limited qty)	129 (Response)	00 (start-stop)
32	0	Analog Input Change Event - any variation	1(read)	06 (no range, or all), 07, 08 (limited qty)		
32	3	Analog Input Change Event - 32-bit with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	3	Analog Input Change Event - 32-bit with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	130 (Unsol. Resp)	17, 28 (index)
32	4	Analog Input Change Event - 16-bit with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	129 (Response)	17, 28 (index)
32	4	Analog Input Change Event - 16-bit with time	1(read)	06 (no range, or all), 07, 08 (limited qty)	130 (Unsol. Resp)	17, 28 (index)
41	1	Analog Output Block - 32-bit	2(write)	17 (index)	129 (Response)	echo of request
50	1	Time and Date - absolute time	1(read)	07, 17 (index)	129 (Response)	07 (limited qty = 1)
50	1	Time and Date - absolute time	2(write)	07, 17 (index)	129 (Response)	07 (limited qty = 1)
60	1	Class 0 data	1(read)	06 (no range, or all)	129 (Response)	00 (start-stop)
60	3	Class 1 data	1(read)	06 (no range, or all)		
60	4	Class 2 data	1(read)	06 (no range, or all)		
60	2	Class 3 data	1(read)	06 (no range, or all)		
80	1	Internal Indications	1(read)	06 (no range, or all)		
80	1	Internal Indications	2(write)	00 (start-stop)		

### 5 Data Points List (outstation only)

This part of Device Profile shows, for each data type, a table defining the data points available in the device or a description of how this information can be obtained if the database is configurable.

<p><b>5.1 Definition of Binary Input Point List:</b></p> <p>List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.</p>	<input type="checkbox"/> Fixed, list shown in table below <input checked="" type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
--	--

Binary Input points list:

Point Index	Name	Event Class Assigned (1, 2, 3 or none)	Name for State when value is 0	Name for State when value is 1	Description
0	BI #0	none	Não está em manual	Está em manual	Manual_R1
1	BI #1	none	Não está em manual	Está em manual	Manual_R2
2	BI #2	none	Não está em manual	Está em manual	Manual_R3
3	BI #3	none	Não está em automático	Está em automático	Automático_R1
4	BI #4	none	Não está em automático	Está em automático	Automático_R2
5	BI #5	none	Não está em automático	Está em automático	Automático_R3
6	BI #6	none	Não está em travado	Está em travado	Travado_R1
7	BI #7	none	Não está em travado	Está em travado	Travado_R2
8	BI #8	none	Não está em travado	Está em travado	Travado_R3
9	BI #9	none	Direto	Inverso	Fluxo_R1
10	BI #10	none	Direto	Inverso	Fluxo_R2
11	BI #11	none	Direto	Inverso	Fluxo_R3
12	BI #12	none	Led apagado	Led acesso	Elevar_R1
13	BI #13	none	Led apagado	Led acesso	Elevar_R2

14	BI #14	none	Led apagado	Led acesso	Elevar_R3
15	BI #15	none	Led apagado	Led acesso	Abaixar_R1
16	BI #16	none	Led apagado	Led acesso	Abaixar_R2
17	BI #17	none	Led apagado	Led acesso	Abaixar_R3
18	BI #18	none	Não acionado no sentido de elevar	Acionado no sentido de elevar	Elevando_R1
19	BI #19	none	Não acionado no sentido de elevar	Acionado no sentido de elevar	Elevando_R2
20	BI #20	none	Não acionado no sentido de elevar	Acionado no sentido de elevar	Elevando_R3
21	BI #21	none	Não acionado no sentido de abaixar	Acionado no sentido de abaixar	Abaixando_R1
22	BI #22	none	Não acionado no sentido de abaixar	Acionado no sentido de abaixar	Abaixando_R2
23	BI #23	none	Não acionado no sentido de abaixar	Acionado no sentido de abaixar	Abaixando_R3
24	BI #24	none	Não acionada	Acionada	Chave Neutro_R1
25	BI #25	none	Não acionada	Acionada	Chave Neutro_R2
26	BI #26	none	Não acionada	Acionada	Chave Neutro_R3
27	BI #27	none	Led apagado	Led acesso	Falha_R1
28	BI #28	none	Led apagado	Led acesso	Falha_R2
29	BI #29	none	Led apagado	Led acesso	Falha_R3
30	BI #30	none	Não atingido	Atingido	Bfmax_R1
31	BI #31	none	Não atingido	Atingido	Bfmax_R2
32	BI #32	none	Não atingido	Atingido	Bfmax_R3
33	BI #33	none	Não atingido	Atingido	Bfmin_R1
34	BI #34	none	Não atingido	Atingido	Bfmin_R2
35	BI #35	none	Não atingido	Atingido	Bfmin_R3
36	BI #36	none	Direto	Inverso	CFP_R1
37	BI #37	none	Direto	Inverso	CFP_R2
38	BI #38	none	Direto	Inverso	CFP_R3
39	BI #39	none	Computador fora da posição neutra	Computador na posição neutra	Zerado_R1
40	BI #40	none	Computador fora da posição neutra	Computador na posição neutra	Zerado_R2
41	BI #41	none	Computador fora da posição neutra	Computador na posição neutra	Zerado_R3
42	BI #42	none	Não acionada	Acionada	Chpol_R1
43	BI #43	none	Não acionada	Acionada	Chpol_R2
44	BI #44	none	Não acionada	Acionada	Chpol_R3
45	BI #45	none	Não acionada	Acionada	Bloqueio subcorrente R1
46	BI #46	none	Não acionada	Acionada	Bloqueio subcorrente R2
47	BI #47	none	Não acionada	Acionada	Bloqueio subcorrente R3
48	BI #48	none	Não acionada	Acionada	Bloqueio sobre corrente R1
49	BI #49	none	Não acionada	Acionada	Bloqueio sobre corrente R2
50	BI #50	none	Não acionada	Acionada	Bloqueio sobre corrente R3
51	BI #51	none	Não acionada	Acionada	Bloqueio fluxo inverso R1
52	BI #52	none	Não acionada	Acionada	Bloqueio fluxo inverso R2
53	BI #53	none	Não acionada	Acionada	Bloqueio fluxo inverso R3
54	BI #54	none	Local	Remoto	Local/Remoto
55	BI #55	none	Porta frontal USB	Porta frontal RS232	USB/RS232
56	BI #56	none	Monofásico	Trifásico	Tipo de operação
57	BI #57	none	Não acionado	Acionado	Atuação pelo nobreak
58	BI #58	none	Não acionada	Acionada	E1 (entrada auxiliar 1)
59	BI #59	none	Não acionada	Acionada	E2 (entrada auxiliar 2)
60	BI #60	none	Não acionada	Acionada	E3 (entrada auxiliar 3)
61	BI #61	none	Não acionada	Acionada	E4 (entrada auxiliar 4)
62	BI #62	none	Não acionada	Acionada	S1 (saída auxiliar 1)
63	BI #63	none	Não acionada	Acionada	S2 (saída auxiliar 2)
64	BI #64	none	Não acionada	Acionada	S3 (saída auxiliar 3)
65	BI #65	none	Não acionada	Acionada	V1 (variável binária virtual 1)
66	BI #66	none	Não acionada	Acionada	V2 (variável binária virtual 2)
67	BI #67	none	Não acionada	Acionada	V3 (variável binária virtual 3)
68	BI #68	none	Não acionada	Acionada	V4 (variável binária virtual 4)
69	BI #69	none	Não acionada	Acionada	V5 (variável binária virtual 5)
70	BI #70	none	Não acionada	Acionada	V6 (variável binária virtual 6)
71	BI #71	none	Não acionada	Acionada	V7 (variável binária virtual 7)
72	BI #72	none	Não acionada	Acionada	V8 (variável binária virtual 8)

73	BI #73	none	Não acionada	Acionada	V9 (variável binária virtual 9)
74	BI #74	none	Não acionada	Acionada	V10 (variável binária virtual 10)

**5.2 Definition of Double-bit Input Point List:**

List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.

- Fixed, list shown in table below  
 Configurable (current list may be shown in table below)  
 Other, explain:

Double-bit Input points list:

Point Index	Name	Event Class Assigned (1, 2, 3 or none)	Name for State when value is 0 (intermediate)	Name for State when value is 1 (off)	Name for State when value is 2 (on)	Name for State when value is 3 (indeterminate)	Description
-------------	------	--	---	--------------------------------------	-------------------------------------	--	-------------

**5.3 Definition of Binary Output Status / Control Relay Output Block Points List:**

List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.

- Fixed, list shown in table below  
 Configurable (current list may be shown in table below)  
 Other, explain:

Binary Output Status and CROB points list:

Point Index	Name	Supported Control Operations										Cancel Currently Running Operation	Name for State when value is 0	Name for State when value is 1	Event Class Assigned (1,2,3 or none)		Description
		Select/ Operate	Direct Operate	Direct Operate – No Ack	Pulse On	Pulse Off	Latch On	Latch Off	Trip	Close	Count > 1				Change	Command	
0	BO #0	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset do Indicador Externo R1
1	BO #1	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset do Indicador Externo R2
2	BO #2	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset do Indicador Externo R3
3	BO #3	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Elevar R1
4	BO #4	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Elevar R2
5	BO #5	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Elevar R3
6	BO #6	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Abaixar R1
7	BO #7	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Abaixar R2
8	BO #8	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Abaixar R3
9	BO #9	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset Quantidade de Registro
10	BO #10	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Elevar banco completo
11	BO #11	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Abaixar banco completo
12	BO #12	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset de contagem de entradas em modo trifásico
13	BO #13	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset contador de atuações em caso de subcorrente R1
14	BO #14	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset contador de atuações em caso de subcorrente R2
15	BO #15	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset contador de atuações em caso de subcorrente R3
16	BO #16	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset contador de bloqueio máximo atingido R1
17	BO #17	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset contador de bloqueio máximo atingido R2
18	BO #18	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset contador de bloqueio máximo atingido R3
19	BO #19	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset contador de neutralização por fluxo inverso R1
20	BO #20	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset contador de neutralização por fluxo inverso R2
21	BO #21	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Reset contador de neutralização por fluxo inverso R3
22	BO #22	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y				none		Resertar tensão máxima na linha R1



9	CI #9	none			Regulador 1 - Contagem de atuações de bloqueio de posição máxima
10	CI #10	none			Regulador 2 - Contagem de atuações de bloqueio de posição máxima
11	CI #11	none			Regulador 3 - Contagem de atuações de bloqueio de posição máxima
12	CI #12	none			Quantidade de entradas em modo trifásico
13	CI #13	none			Neutralizações por falta de energia usando nobreak
14	CI #14	none			Quantidade de registros na pilha
15	CI #15	none			Posição atual da pilha de registros

### 5.5 Definition of Analog Input Point List:

List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.

- Fixed, list shown in table below  
 Configurable (current list may be shown in table below)  
 Other, explain:

Analog Input points list:

Point Index	Name	Event Class Assigned (1, 2, 3 or none)	Transmitted Value		Scaling				Description
			Min int / ft	Max int / ft	Multiplier	Offset	Units	Resolution	
0	AI #0	none	/	/	100	0		0,01	Firmware [informa versão firmware]
1	AI #1	none	/	/	100	0		0,01	Hardware [informa versão hardware]
2	AI #2	none	/	/	1	0		1	Número serie [informa n.º série]
3	AI #3	none	/	/	1	0		1	Ano fabricação [informa ano fabricação]
4	AI #4	none	/	/	1	0		1	Idioma [informa idioma]
5	AI #5	none	/	/	1	0		1	TCON [Tipo de conexão do CAQ-1 para compensação]
6	AI #6	none	/	/	1	0		1	GDL [Grau de liberdade]
7	AI #7	none	/	/	1	0		1	MTR [Seleciona o compensador mestre]
8	AI #8	none	/	/	1	0		1	TPES [Tempo de permanência em sincronismo]
9	AI #9	none	/	/	1	0		1	TNOBREAK [Tempo para neutralização com nobreak]
10	AI #10	none	/	/	1	0		1	DTAQ [Período de aquisição de dados]
11	AI #11	none	/	/	1	0		1	HCMP [Hora para auditoria do rastreamento]
12	AI #12	none	/	/	1	0		1	SCMP [Dia da semana para auditoria do rastreamento]
13	AI #13	none	/	/	1	0		1	HESP_P2 [Habilita mensagem espontânea P2]
14	AI #14	none	/	/	1	0		1	ENDREM_P2 [Endereço para mensagem espontânea P2]
15	AI #15	none	/	/	1	0		1	HESP_P3 [Habilita mensagem espontânea P3]
16	AI #16	none	/	/	1	0		1	ENDREM_P3 [Endereço para mensagem espontânea P3]
17	AI #17	none	/	/	1	0		1	ESERIAL [Endereço para comunicação serial]
18	AI #18	none	/	/	1	0		1	BAUD1 [Taxa de transmissão de dados P1]
19	AI #19	none	/	/	1	0		1	BAUD2 [Taxa de transmissão de dados P2]
20	AI #20	none	/	/	1	0		1	BAUD3 [Taxa de transmissão de dados P3]
21	AI #21	none	/	/	1	0		1	Senha para operador
22	AI #22	none	/	/	1	0		1	Senha para administrador
23	AI #23	none	/	/	10	0	A	0,1	INEUT [Corrente de neutro]
24	AI #24	none	/	/	1	0		1	TAP_R1 [tap atual R1]
25	AI #25	none	/	/	1	0		1	Manual_Automatico_Travado_R1 [modo operação R1]
26	AI #26	none	/	/	1	0		1	TAPMAX_R1 [tap máximo R1]
27	AI #27	none	/	/	1	0		1	TAPMIN_R1 [tap mínimo R1]
28	AI #28	none	/	/	1	0	Hz	1	FREQ [Hz]_R1 [frequência R1]
29	AI #29	none	/	/	100	0		0,01	FPOT_R1 [fator de potência R1]
30	AI #30	none	/	/	100	0		0,01	FPMIF [Fator de potência mínimo indutivo R1]
31	AI #31	none	/	/	100	0		0,01	FPMCF [Fator de potência mínimo capacitivo R1]
32	AI #32	none	/	/	100	0		0,01	VFMAX [tensão máxima na fonte atingida R1]
33	AI #33	none	/	/	10	0	V	0,1	TBLF [V]_R1 [tensão secundária fonte R1]
34	AI #34	none	/	/	10	0	mA	0,1	IFb [mA]_R1 [corrente secundária fonte R1]
35	AI #35	none	/	/	100	0	kV	0,01	VF [kV]_R1 [tensão primária fonte R1]
36	AI #36	none	/	/	10	0	A	0,1	IF [A]_R1 [corrente primária fonte R1]
37	AI #37	none	/	/	10	0	KVA	0,1	S [kVA]_R1 [potência aparente R1]
38	AI #38	none	/	/	10	0	kW	0,1	P [kW]_R1 [potência ativa R1]
39	AI #39	none	/	/	10	0	kVAr	0,1	Q [kVAr]_R1 [potência reativa R1]
40	AI #40	none	/	/	10	0		0,1	RTPC_R1 [relação de tensão R1]
41	AI #41	none	/	/	1	0		1	RTCC_R1 [relação corrente R1]
42	AI #42	none	/	/	1	0		1	HCOMP [habilita compensador R1]
43	AI #43	none	/	/	1	0		1	CCP [critério para compensação R1]
44	AI #44	none	/	/	100	0		0,01	FP1 [parâmetro 1 para faixa do FP para regulação R1]
45	AI #45	none	/	/	100	0		0,01	FP2 [parâmetro 2 para faixa do FP para regulação R1]
46	AI #46	none	/	/	10	0	V	0,1	VREF_R1 [tensão de referência MD R1]
47	AI #47	none	/	/	10	0	V	0,1	INS_R1 [insensibilidade R1]
48	AI #48	none	/	/	1	0	s	1	TMP_R1 [temporização R1]
49	AI #49	none	/	/	1	0		1	BMAX [bloqueio físico máximo do computador R1]
50	AI #50	none	/	/	1	0		1	BSUBC [bloqueio por subcorrente R1]
51	AI #51	none	/	/	1	0		1	BSOBC [bloqueio por sobre corrente R1]

52	AI #52	none	/	/	1	0		1	PBCS [posição para bloqueio em caso de subcorrente R1]
53	AI #53	none	/	/	1	0		1	DEFVC [defasagem V e I R1]
54	AI #54	none	/	/	1	0		1	DTAP [diferença fixa para o mestre R1]
55	AI #55	none	/	/	1	0		1	MIPCOM [modo indicação comutador R1]
56	AI #56	none	/	/	1	0		1	TAP_R1 [tap atual R2]
57	AI #57	none	/	/	1	0		1	Manual_Automatico_Travado_R2 [modo operação R2]
58	AI #58	none	/	/	1	0		1	TAPMAX_R2 [tap máximo R2]
59	AI #59	none	/	/	1	0		1	TAPMIN_R2 [tap mínimo R2]
60	AI #60	none	/	/	1	0	Hz	1	FREQ [Hz]_R2 [frequência R2]
61	AI #61	none	/	/	100	0		0,01	FPOT_R2 [fator de potência R2]
62	AI #62	none	/	/	100	0		0,01	FPMIF [Fator de potência mínimo indutivo R2]
63	AI #63	none	/	/	100	0		0,01	FPMCF [Fator de potência mínimo capacitivo R2]
64	AI #64	none	/	/	100	0		0,01	VFMAX [tensão máxima na fonte atingida R2]
65	AI #65	none	/	/	10	0	V	0,1	TBLF [V]_R2 [tensão secundária fonte R2]
66	AI #66	none	/	/	10	0	mA	0,1	IFb [mA]_R2 [corrente secundária fonte R2]
67	AI #67	none	/	/	100	0	kV	0,01	VF [kV]_R2 [tensão primária fonte R2]
68	AI #68	none	/	/	10	0	A	0,1	IF [A]_R2 [corrente primária fonte R2]
69	AI #69	none	/	/	10	0	KVA	0,1	S [kVA]_R2 [potência aparente R2]
70	AI #70	none	/	/	10	0	kW	0,1	P [kW]_R2 [potência ativa R2]
71	AI #71	none	/	/	10	0	kVAr	0,1	Q [kVAr]_R2 [potência reativa R2]
72	AI #72	none	/	/	10	0		0,1	RTPC_R2 [relação de tensão R2]
73	AI #73	none	/	/	1	0		1	RTCC_R2 [relação corrente R2]
74	AI #74	none	/	/	1	0		1	HCOMP [habilita compensador R2]
75	AI #75	none	/	/	1	0		1	CCP [critério para compensação R2]
76	AI #76	none	/	/	100	0		0,01	FP1 [parâmetro 1 para faixa do FP para regulação R2]
77	AI #77	none	/	/	100	0		0,01	FP2 [ parâmetro 2 para faixa do FP para regulação R2]
78	AI #78	none	/	/	10	0	V	0,1	VREF_R2 [tensão de referência MD R2]
79	AI #79	none	/	/	10	0	V	0,1	INS_R2 [insensibilidade R2]
80	AI #80	none	/	/	1	0	s	1	TMP_R2 [temporização R2]
81	AI #81	none	/	/	1	0		1	BMAX [bloqueio físico máximo do comutador R2]
82	AI #82	none	/	/	1	0		1	BSUBC [bloqueio por subcorrente R2]
83	AI #83	none	/	/	1	0		1	BSOBC [bloqueio por sobre corrente R2]
84	AI #84	none	/	/	1	0		1	PBCS [posição para bloqueio em caso de subcorrente R2]
85	AI #85	none	/	/	1	0		1	DEFVC [defasagem V e I R2]
86	AI #86	none	/	/	1	0		1	DTAP [diferença fixa para o mestre R2]
87	AI #87	none	/	/	1	0		1	MIPCOM [modo indicação comutador R2]
88	AI #88	none	/	/	1	0		1	TAP_R3 [tap atual R3]
89	AI #89	none	/	/	1	0		1	Manual_Automatico_Travado_R3 [modo operação R3]
90	AI #90	none	/	/	1	0		1	TAPMAX_R3 [tap máximo R3]
91	AI #91	none	/	/	1	0		1	TAPMIN_R3 [tap mínimo R3]
92	AI #92	none	/	/	1	0	Hz	1	FREQ [Hz]_R3 [frequência R3]
93	AI #93	none	/	/	100	0		0,01	FPOT_R3 [fator de potência R3]
94	AI #94	none	/	/	100	0		0,01	FPMIF [Fator de potência mínimo indutivo R3]
95	AI #95	none	/	/	100	0		0,01	FPMCF [Fator de potência mínimo capacitivo R3]
96	AI #96	none	/	/	100	0		0,01	VFMAX [tensão máxima na fonte atingida R3]
97	AI #97	none	/	/	10	0	V	0,1	TBLF [V]_R3 [tensão secundária fonte R3]
98	AI #98	none	/	/	10	0	mA	0,1	IFb [mA]_R3 [corrente secundária fonte R3]
99	AI #99	none	/	/	100	0	kV	0,01	VF [kV]_R3 [tensão primária fonte R3]
100	AI #100	none	/	/	10	0	A	0,1	IF [A]_R3 [corrente primária fonte R3]
101	AI #101	none	/	/	10	0	KVA	0,1	S [kVA]_R3 [potência aparente R3]
102	AI #102	none	/	/	10	0	kW	0,1	P [kW]_R3 [potência ativa R3]
103	AI #103	none	/	/	10	0	kVAr	0,1	Q [kVAr]_R3 [potência reativa R3]
104	AI #104	none	/	/	10	0		0,1	RTPC_R3 [relação de tensão R3]
105	AI #105	none	/	/	1	0		1	RTCC_R3 [relação corrente R3]
106	AI #106	none	/	/	1	0		1	HCOMP [habilita compensador R3]
107	AI #107	none	/	/	1	0		1	CCP [critério para compensação R3]
108	AI #108	none	/	/	100	0		0,01	FP1 [parâmetro 1 para faixa do FP para regulação R3]
109	AI #109	none	/	/	100	0		0,01	FP2 [ parâmetro 2 para faixa do FP para regulação R3]
110	AI #110	none	/	/	10	0	V	0,1	VREF_R3 [tensão de referência MD R3]
111	AI #111	none	/	/	10	0	V	0,1	INS_R3 [insensibilidade R3]
112	AI #112	none	/	/	1	0	s	1	TMP_R3 [temporização R3]
113	AI #113	none	/	/	1	0		1	BMAX [bloqueio físico máximo do comutador R3]
114	AI #114	none	/	/	1	0		1	BSUBC [bloqueio por subcorrente R3]
115	AI #115	none	/	/	1	0		1	BSOBC [bloqueio por sobre corrente R3]
116	AI #116	none	/	/	1	0		1	PBCS [posição para bloqueio em caso de subcorrente R3]
117	AI #117	none	/	/	1	0		1	DEFVC [defasagem V e I R3]
118	AI #118	none	/	/	1	0		1	DTAP [diferença fixa para o mestre R3]
119	AI #119	none	/	/	1	0		1	MIPCOM [modo indicação comutador R3]

## 5.6 Definition of Analog Output Status / Analog Output Block Point List:

List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.

- Fixed, list shown in table below  
 Configurable (current list may be shown in table below)  
 Other, explain:

Analog Output points list:

Point Index	Supported Control operations				Transmitted Value		Scaling		Units	Resolu tion	Event Class Assigned (1, 2, 3 or none)		Description
	Name	Select/ Operate	Direct Operate	Direct Operate - No Ack	Min	Max	Min	Max			Change	Comman d	
0	AO #0				0	3				1	none	none	TCON [Tipo de conexão do CAQ-1 para compensação]
1	AO #1				0	16				1	none	none	GDL [Grau de liberdade]
2	AO #2				1	3				1	none	none	MTR [Seleciona o compensador mestre]
3	AO #3				10	1440				1	none	none	TPES [Tempo de permanência em sincronismo]
4	AO #4				0	600				1	none	none	TNOBREAK [Tempo para neutralização com nobreak]
5	AO #5				1	60				1	none	none	DTAQ [Período de aquisição de dados]
6	AO #6				0	23				1	none	none	HCMP [Hora para auditoria do rastreamento]
7	AO #7				0	8				1	none	none	SCMP [Dia da semana para auditoria do rastreamento]
8	AO #8				0	1				1	none	none	HESP_P2 [Habilita mensagem espontânea P2]
9	AO #9				0	65534				1	none	none	ENDREM_P2 [Endereço para mensagem espontânea P2]
10	AO #10				0	1				1	none	none	HESP_P3 [Habilita mensagem espontânea P3]
11	AO #11				0	65534				1	none	none	ENDREM_P3 [Endereço para mensagem espontânea P3]
12	AO #12				0	65534				1	none	none	EESERIAL [Endereço para comunicação serial]
13	AO #13				0	7				1	none	none	BAUD1 [Taxa de transmissão de dados P1]
14	AO #14				0	7				1	none	none	BAUD2 [Taxa de transmissão de dados P2]
15	AO #15				0	7				1	none	none	BAUD3 [Taxa de transmissão de dados P3]
16	AO #16				0	999999				1	none	none	Senha para operador
17	AO #17				0	999999				1	none	none	Senha para administrador
18	AO #18				0	2				1	none	none	Manual_Automatico_Travado R1 [modo operação R1]
19	AO #19				1	500				0,1	none	none	RTPC_R1 [relação de tensão R1]
20	AO #20				1	6000				1	none	none	RTCC_R1 [relação corrente R1]
21	AO #21				0	1				1	none	none	HCOMP [habilita compensador R1]
22	AO #22				0	3				1	none	none	CCP [critério para compensação R1]
23	AO #23				0,5	1				0,01	none	none	FP1 [parâmetro 1 para faixa do FP para regulação R1]
24	AO #24				0,5	1				0,01	none	none	FP2 [ parâmetro 2 para faixa do FP para regulação R1]
25	AO #25				90	135				0,1	none	none	VREF_R1 [tensão de referência MD R1]
26	AO #26				0,8	5				0,1	none	none	INS_R1 [insensibilidade MD R1]
27	AO #27				10	180				1	none	none	TMP_R1 [temporização MD R1]
28	AO #28				8	16				1	none	none	BMAX [bloqueio físico máximo do comutador R1]
29	AO #29				0	100				1	none	none	BSUBC [bloqueio por subcorrente R1]
30	AO #30				50	200				1	none	none	BSOBC [bloqueio por sobre corrente R1]
31	AO #31				0	8				1	none	none	PBCS [posição para bloqueio em caso de subcorrente R1]
32	AO #32				0	2				1	none	none	DEFVC [defasagem V e I R1]
33	AO #33				-4	4				1	none	none	DTAP [diferença fixa para o mestre R1]
34	AO #34				0	7				1	none	none	MIPCOM [modo indicação comutador R1]
35	AO #35				0	2				1	none	none	Manual_Automatico_Travado R2 [modo operação R2]
36	AO #36				1	500				0,1	none	none	RTPC_R2 [relação de tensão R2]
37	AO #37				1	6000				1	none	none	RTCC_R2 [relação corrente R2]
38	AO #38				0	1				1	none	none	HCOMP [habilita compensador R2]
39	AO #39				0	3				1	none	none	CCP [critério para compensação R2]
40	AO #40				0,5	1				0,01	none	none	FP1 [parâmetro 1 para faixa do FP para regulação R2]
41	AO #41				0,5	1				0,01	none	none	FP2 [ parâmetro 2 para faixa do FP para regulação R2]
42	AO #42				90	135				0,1	none	none	VREF_R2 [tensão de referência MD R2]
43	AO #43				0,8	5				0,1	none	none	INS_R2 [insensibilidade MD R2]
44	AO #44				10	180				1	none	none	TMP_R2 [temporização MD R2]
45	AO #45				8	16				1	none	none	BMAX [bloqueio físico máximo do comutador R2]
46	AO #46				0	100				1	none	none	BSUBC [bloqueio por subcorrente R2]
47	AO #47				50	200				1	none	none	BSOBC [bloqueio por sobre corrente R2]
48	AO #48				0	8				1	none	none	PBCS [posição para bloqueio em caso de subcorrente R2]
49	AO #49				0	2				1	none	none	DEFVC [defasagem V e I R2]
50	AO #50				-4	4				1	none	none	DTAP [diferença fixa para o mestre R2]
51	AO #51				0	7				1	none	none	MIPCOM [modo indicação comutador R2]
52	AO #52				0	2				1	none	none	Manual_Automatico_Travado R3 [modo operação R3]
53	AO #53				1	500				0,1	none	none	RTPC_R3 [relação de tensão R3]
54	AO #54				1	6000				1	none	none	RTCC_R3 [relação corrente R3]
55	AO #55				0	1				1	none	none	HCOMP [habilita compensador R3]
56	AO #56				0	3				1	none	none	CCP [critério para compensação R3]
57	AO #57				0,5	1				0,01	none	none	FP1 [parâmetro 1 para faixa do FP para regulação R3]
58	AO #58				0,5	1				0,01	none	none	FP2 [ parâmetro 2 para faixa do FP para regulação R3]
59	AO #59				90	135				0,1	none	none	VREF_R3 [tensão de referência MD R3]
60	AO #60				0,8	5				0,1	none	none	INS_R3 [insensibilidade MD R3]
61	AO #61				10	180				1	none	none	TMP_R3 [temporização MD R3]
62	AO #62				8	16				1	none	none	BMAX [bloqueio físico máximo do comutador R3]
63	AO #63				0	100				1	none	none	BSUBC [bloqueio por subcorrente R3]
64	AO #64				50	200				1	none	none	BSOBC [bloqueio por sobre corrente R3]
65	AO #65				0	8				1	none	none	PBCS [posição para bloqueio em caso de subcorrente R3]
66	AO #66				0	2				1	none	none	DEFVC [defasagem V e I R3]
67	AO #67				-4	4				1	none	none	DTAP [diferença fixa para o mestre R3]
68	AO #68				0	7				1	none	none	MIPCOM [modo indicação comutador R3]

<b>5.7 Definition of File Names that may be read or written:</b>	<input checked="" type="checkbox"/> Fixed, list shown in table below <input checked="" type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
--	---

Sequential Files list:

		Authentication Required for:			
File Name	Event Class Assigned (1, 2, 3 or none)	Read	Write	Delete	Description

<b>5.8 Definition of Octet String and Extended Octet String Point List:</b>	<input checked="" type="checkbox"/> Fixed, list shown in table below <input checked="" type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
<i>List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.</i>	

Octet String and Extended Octet String points list:

Point Index	Name	Event Class Assigned (1, 2, 3 or none)	Group Number used to transport the object	Description

<b>5.9 Definition of Virtual Terminal Port Numbers:</b>	<input checked="" type="checkbox"/> Fixed, list shown in table below <input checked="" type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
<i>List of addressable points. Points that do not exist (for example, because an option is not installed) are omitted from the table.</i>	

Ports list:

Virtual Port Number (Point Index)	Name	Event Class Assigned (1, 2, 3 or none)	Description

<b>5.10 Definition of Data Set Prototypes:</b>	<input type="checkbox"/> Fixed, list shown in table below <input type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
<i>List of all data set prototypes. The following table is repeated for each Data Set Prototype defined.</i>	

<b>5.11 Definition of Data Set Descriptors:</b>	<input type="checkbox"/> Fixed, list shown in table below <input type="checkbox"/> Configurable (current list may be shown in table below) <input type="checkbox"/> Other, explain:
<i>List of all data set descriptors. The following table is repeated for each Data Set Descriptor defined.</i>	

----- End of Device Profile for Reference Device -----